USB 3.1 Gen1 Type-C to HDMI Adapter

User Manual

Ver. 1.00

All brand names and trademarks are properties of their respective owners.

Contents:

Chapter 1: Introduction 3
1.1 Product Introduction 3
1.2 Features 4
1.3 System Requirements 4
1.4 Package Contents 5
Chapter 2: Getting Started 5
2.1 Driver Installation 5
2.1.1 Installation for Windows 5
2.1.2 Installation for Mac OS X 7

Chapter 1: Introduction

1.1 Product Introduction

This USB 3.1 Gen1 Type-C to HDMI Adapter turns an available USB 3.1 Type-C port into an HDMI output, with high resolution video support - a convenient external video solution that makes it easy to add multi-monitor capability to a USB 3.1-enabled desktop or laptop computer

Leveraging the high-bandwidth (5Gbps) Super-Speed USB 3.1 interface, the adapter functions as an external graphics card to deliver smooth, high-definition content to your HDMI display. The adapter can be used to mirror you're your primary desktop, showing the same image on each display, or to extend your desktop to double your workspace and increase your productivity.

1.2 Features

- Add-on monitor, LCD or projector through Type-C connectivity
- Supports widescreen aspect ratio of 16:9 Full HD 1080 video streaming
- Supports resolutions up to 2560x1440
- Low power consumption via USB Bus Power Supply
- Supports desktop display mirror, extended, and screen rotation modes
- Up to six USB-C graphic adapters working simultaneously
- Audio output through HDMI
- Compatible with Windows power management hibernate and suspend modes

1.3 System Requirements

- Windows® 7/8/8.1/10 (32/64 bit); Mac OS X 10.8 or above
- Available USB-C port

1.4 Package Contents

- 1 x USB 3.1 Gen1 Type-C to HDMI Adapter
- 1 x Driver CD
- 1 x User Manual

Chapter 2: Getting Started

2.1 Driver Installation

The following section shows you how to install the USB 3.1 Gen1 Type-C to HDMI Adapter driver on different operating systems.

Important! Please connect the USB 3.1 Gen1 Type-C to HDMI Adapter to your PC before the install.

2.1.1 Installation for Windows

1. Insert the provided CD into your CD-ROM drive. The CD-ROM will start automatically. The following screen will show up and please click "**Install Driver**".



*Note: Actual image may vary

Note: If the install program doesn't run automatically, please locate and double-click on the **Autorun.exe** file in the CD to launch the install program.

2. Please click "**USB 3.0 to HDMI**".




*Note: Actual image may vary


3. Follow the instructions on screen to install the driver.

2.1.2 Installation for Mac OS X

1. Insert the provided CD into your CD-ROM drive.
2. Double-click the "**USB Graphics**" disc icon, double-click package file "**mac.dmg**", the following "**USB Graphics**" virtual disk will be appeared on the Desktop of your Mac OS X system. Then double click "**Drivers**" folder.



3. Double Click "**USB 2.0/3.0 to HDMI Adapter**" folder.



4. Select “**DisplayLink Software Installer**” to begin installing the DisplayLink Driver on your Mac.



5. Follow the instructions on screen to install the driver. After driver installation is complete, you must restart your computer.